

## USER MANUAL Jan. 2026

### Wi-Fi<sup>3</sup> NestBox Inspection Camera



#### ABOUT:-

**Wi-Fi<sup>3</sup> NestBox Camera** connects to most android & iOS devices, records HQ video and captures quality photos directly from the tree tops. Operates pretty much anywhere; **Mobile Service is NOT required**.

#### Features

- Great quality pictures & video with date time imprint
- Wi-Fi to android & IOS devices - no internet required
- Rotating 360° camera Lens – suits Hollows - Nest & Bat boxes
- Up to 6 hours run time from a single charge
- Video & photo downloads direct to your device
- Includes Smart battery with protective nylon pouch & cable ties
- Charge using any 5 volt/ 2 amp micro USB phone charger
- Includes eco-friendly storage case
- 12 months Warranty

## Step 1 = Install the Azdome app on your device



### 1. Allow app requests. Android shown (IOS may vary) –




<https://play.google.com/store/apps/details?id=cn.com.blackview.azdome>

<https://apps.apple.com/us/app/azdome/id1449342214>

## Step 2 = Following installation - Close the app

When installation is completed the 'Device' screen will open.



You can install the app on multiple devices, however the Wi-Fi<sup>3</sup> NestCam can only connect to one device at a time.

## Using the Camera for the first time:

On your device **SETTINGS**: Turn **Mobile Data OFF & Disable any VPN**

### 1. Setting up your device for connection to the Camera's Wi-Fi network

This only has to be done once.

- Plug Camera's power cable into the USB socket on the top of the Smart Battery. Hold down the Battery's power button, release it when the camera's white illuminator comes be **ON** (this confirms the camera is receiving power)
- **WAIT 30 seconds for the camera to fully boot up**
- On your mobile device go to **SETTINGS** – turn **ON** **Wi-Fi**
- Then **Search available networks**
- Select '**M330\_xxxxxx.....**' network & enter the password **12345678**
- The Message..... **"connected no internet"** is displayed - OK

### 2. On your device - open the AZDOME App *(android shown below- iOS may vary)*

The blue Help screen opens; tap "**Add Device**"


On **Add Device screen** tap "**Screen Recorder**"

On the **Device Screen**, tap on the "**M330\_xxxxxx**" image

**Live Video Preview** screen opens displaying live video from the Wi-Fi Camera

Press **Recording** button to stop the camera recording

To take a photo during recording, touch screen & press **Snapshot button**



These two screens only appear during initialisation and setup

DEVICE SCREEN

Live Video Preview

Hold down the Power button on the Smart battery, release it when the Camera illuminator led goes out and then close the app.

In future when you open the app it will take you to the **DEVICE SCREEN**.

## Everyday use of the Wi-Fi<sup>3</sup> Camera:


### Step 1:

Plug Camera's power cable into the USB socket on the top of the Smart Battery Hold down the Battery's power button, release it when the camera's white illuminator comes be **ON** (this confirms the camera is receiving power) it will start transmitting via Wi-Fi.

### Step 2:

- On your mobile device go to **SETTINGS** – turn **ON** **Wi-Fi**
- Select '**M330\_xxxxx.....**' network
- Connection is automatic as it has remembered the password

The blue app screen appears followed by the **Device Screen**, tap on the **M330.xxxx** option and the **LIVE VIDEO PREVIEW** screen will open.



## Record Video & capture Photos:


Camera starts recording automatically when it powers up and indicated by the flashing red record icon displayed on the **Live Video Preview** screen.

1. Tap **STOP** to pause Recording: Tap **Recording** to start recording again
2. **To capture a Photo:** touch the live video screen and press “**snapshot**” when it appears.

## Download Photos & Videos from the Camera to your device

Photos and videos are stored in the “Photo Album” on the Wi-Fi Camera’s internal memory. They can be downloaded using the app, your device must be Wi-Fi connected to the camera.

Power up the camera and connect to its Wi-Fi network as previously outlined, then open the app.



On the **Live Video Preview** screen, tap **Stop** to end recording. Then tap **Dashcam Albums** to access the camera’s image files.


The **Photo Album** screen provides access to all stored files in chronological order; videos located in either the **Event** or **Video folder** and photos in the **Photo folder**.

Tap on a file to open it in a new screen where you can either **Download** or **Delete** the file, hit return goes back to the previous screen where you can select the next file for processing. It takes about 1 second to download a photo and about 15 seconds to download a 1 minute long video. Use the return arrow to go back to the **Live Video Preview** screen.

Search your device to locate the downloaded files in your **Local Album**.

## Use the app to View any Downloaded files on your device

You can access the downloaded files on your device using the app. The camera does not need to be ON as no Wi-Fi connection is required.



Open the app. **ON DEVICE SCREEN** tap the **MINE** option on the very bottom right hand side of the screen to access your devices **Photo Album**. Videos located in either the **Event** or **Video folder** and photos in the **Photo folder**. Tap on a file to open it in a new preview screen where you can either **Delete** or **Share** the file.

### ***SMART BATTERY - charging procedure:***

Full size **USB** sockets are **Power OUT only** and **CAN NOT** be used for charging.



- *Smart Battery's micro USB* socket is for charging
- Use a 5 volt/ 2-amp micro USB phone charger cable
- Follow safe charging procedures
- Charging is automatic; leds show charge status
- When fully Charged all 4 leds will remain lit
- Typical charge time is 3~4 hours
- Camera run - time < 7 hours on a full charge

Charge battery every 3 months - do not store for extended periods in a discharged state.

## NEST BOX CAMERA GUIDE RAIL: *a nifty idea from a customer*



Navigating your camera into the Nest Box entry port can be made a lot simpler by the addition of a camera guide rail.

20 ~ 25mm square hardwood same height of the box is recommended. It needs to overhang the entry port by 1~2 mm. Bring the camera into contact with the box, slide it across to the guide then slide it up to the hole. Too easy!

### Camera Settings:

These may be accessed using the app. However we do not recommend changing the settings as there is potential to lock yourself out of the Wi-Fi network.

### Mounting Tips & Advice:

- “SD card error” go into the settings option & format the SD card
- Secure protective Battery Pouch to your pole using the cable ties
- To avoid possible OVERHEATING Do NOT exceed 20 minutes of continuous running. Unplug camera from Smart Battery when not in use
- Do NOT change the Wi-Fi network Password. If you forget your new password the camera will be rendered totally useless.
- “**Failed to get device information**” message - turn Off mobile data in your phone settings then reconnect to the camera’s **M330 xxx**’ Wi-Fi network (enter the password 12345678 as outlined on page 3).

The **Wi-Fi Camera** is compatible with many IOS & Android devices but not all. If your camera has been working fine then encounters a problem: check that you still have a Wi-Fi connection. It can be lost if you move your device too far from the Camera. Problems may also arise following a device firmware update.

**We make no guarantee that this product is compatible with all available devices.**  
**Your camera has been tested on a Samsung phone - Lenovo tablet & iPad just prior to being posted to ensure that it is functioning properly.**

Manufactured by:

Brite Star Pty Ltd. Mornington Victoria [sales@starweb.com.au](mailto:sales@starweb.com.au) 0400755431